RELIABLE RACING
ESTABLISHED 1965

RRS COUSE SETTER'S MEASURING TAPE OWNER'S MANUAL

DO NOT DISASSEMBLE

- CAUTION: Tape unit contains a tension spring which may cause serious injury.
- Always wear safety goggles and other necessary safety equipment when working with power tape measures.
- Prevent uncontrolled tape rewind. Hold retracting tape between thumb and finger to control speed. Gloves are strongly suggested to avoid cuts.

To Adjust Tension:

1. Loosen (do not remove) the six screws on the spring housing locking ring. Hold the spring housing to prevent it from turning
2. To decrease tension, allow the housing to rotate counter clockwise. To increase the tension, turn the housing clockwise.
3. Tighten the six screws on the spring housing locking ring to keep spring tension set.

To replace blade:

1. Loosen (do not remove) the six screws on the spring housing locking ring, allowing the housing to revolve and release all tension.
2. Detach worn or broken tape by loosening the tape refill screw at the center hub.
3. Insert a new tape with the unprinted side toward the hub.
4. Secure it with the tape refill screw.
5. Slowly wind the housing in a clockwise direction allowing the tape to rewind completely (about 4 turns for a 15M tape and 8 turns for a 30M tape)
6. Tighten 2 to 3 screws on the spring housing locking ring and pull the tape out to 15M 5 CM or 30M 5 CM. If the tape pulls out past this point, tighten the tension by another partial clockwise turn of the housing. If the tape stops short, release the housing part of a turn
7. Once adjusted. Let the tape rewind and tighten all screws securely.

Note: Tapes are not under warranty. Replacement tapes are available at www.reliableracing.com

#42839 15M Replacement Tape #42841 30M Replacement. Tape

643 UPPER GLEN ST., QUEENSBURY, NY 12804
(518) 793-5677 • FAX # (518) 793-6491